

ANALYZED BY:

Anresco Laboratories
 1375 Van Dyke Avenue,
 San Francisco, CA 94124

CUSTOMER:

Wana Wellness
 1845 Skyway Drive
 Longmont, CO 80504


SAMPLE INFORMATION

Sample No.: 1329149
Product Name: Wana D9 Optimal Fast Asleep Dream Berry Gummy
Matrix: Edible (Gummy)
Lot #: 0018725WAF-A0808

Date Collected: 08/11/2025
Date Received: 08/11/2025
Date Reported: 08/16/2025

TEST SUMMARY

Cannabinoid Profile: ✔ Tested
Residual Solvent Screen: ✔ Pass
Foreign Material: ✔ Pass

Pesticide Residue Screen: ✔ Pass
Heavy Metal Screen: ✔ Pass
Mycotoxin Screen: ✔ Pass

Cannabinoid Profile ✔ Tested

08/14/2025

Method: MF-CHEM-15
Instrument: Liquid Chromatography Diode Array Detector (LC-DAD)
Limit of Detection 0.0333 mg/g
Limit of Quantitation 0.1000 mg/g

Cannabinoid	mg/g	%	mg/serving
Δ8-THC	ND	ND	ND
Δ9-THC	0.48	0.048	2.30
Δ9-THCA	ND	ND	ND
THCV	ND	ND	ND
THCVA	ND	ND	ND
CBD	2.48	0.248	11.76
CBDA	ND	ND	ND
CBC	ND	ND	ND
CBCA	ND	ND	ND
CBDV	ND	ND	ND
CBG	0.51	0.051	2.42
CBGA	ND	ND	ND
CBN	0.49	0.049	2.33
Exo-THC	ND	ND	ND
(6aR,9R)-Δ10-THC	ND	ND	ND
(6aR,9S)-Δ10-THC	ND	ND	ND
9(R)-Hexahydrocannabinol	ND	ND	ND
9(S)-Hexahydrocannabinol	ND	ND	ND
Δ8-THC-O-Acetate	ND	ND	ND
Δ9-THC-O-Acetate	ND	ND	ND
THC-O-Phosphate	NT	NT	NT
Total THC	0.48	0.048	2.30
Total CBD	2.48	0.248	11.76
Total Cannabinoids	3.97	0.397	18.81
Sum of Cannabinoids	3.97	0.397	18.81
Serving Weight (g)	4.7417		

Total THC = Δ8-THC + Δ9-THC + (0.877 * THCA)
 Total CBD = CBD + (0.877 * CBDA)
 Total Cannabinoids = Σ (neutral cannabinoids) + [0.877 * Σ (acidic cannabinoids)]

Comments Insufficient sample amount for retesting.

Pesticide Residue Screen ✔ Pass

Method: MF-CHEM-13
Instrument: Liquid Chromatography Tandem Mass Spectrometry (LC-MS/MS) & Gas Chromatography Tandem Mass Spectrometry (GC-MS/MS)

Analyte	LOD/LOQ (ppm)	Findings (ppm)	Limit (ppm)	Status
Abamectin	0.015/0.05	ND	0.05	Pass
Acephate	0.003/0.01	ND	0.01	Pass
Acequinocyl	0.003/0.01	ND	0.01	Pass

Analyte	LOD/LOQ (ppm)	Findings (ppm)	Limit (ppm)	Status
Acetamiprid	0.003/0.01	ND	0.01	Pass
Aldicarb	0.003/0.01	ND	0.01	Pass
Azoxystrobin	0.003/0.01	ND	0.01	Pass
Bifenazate	0.003/0.01	ND	0.01	Pass
Bifenthrin	0.003/0.01	ND	0.01	Pass
Boscalid	0.003/0.01	ND	0.01	Pass
Captan	0.250/0.7	ND	0.7	Pass
Carbaryl	0.003/0.01	ND	0.01	Pass
Carbofuran	0.003/0.01	ND	0.01	Pass
Chlorantraniliprole	0.003/0.01	ND	0.01	Pass
Chlordane	0.020/0.06	ND	0.06	Pass
Chlorfenapyr	0.015/0.05	ND	0.05	Pass
Chlorpyrifos	0.003/0.01	ND	0.01	Pass
Clofentezine	0.003/0.01	ND	0.01	Pass
Coumaphos	0.003/0.01	ND	0.01	Pass
Cyfluthrin	0.015/0.05	ND	0.05	Pass
Cypermethrin	0.015/0.05	ND	0.05	Pass
Daminozide	0.003/0.01	ND	0.01	Pass
DDVP (Dichlorvos)	0.003/0.01	ND	0.01	Pass
Diazinon	0.003/0.01	ND	0.01	Pass
Dimethoate	0.003/0.01	ND	0.01	Pass
Dimethomorph	0.003/0.01	ND	0.01	Pass
Ethoprop(hos)	0.003/0.01	ND	0.01	Pass
Etofenprox	0.003/0.01	ND	0.01	Pass
Etoxazole	0.003/0.01	ND	0.01	Pass
Fenhexamid	0.007/0.02	ND	0.02	Pass
Fenoxycarb	0.003/0.01	ND	0.01	Pass
Fenpyroximate	0.007/0.02	ND	0.02	Pass
Fipronil	0.003/0.01	ND	0.01	Pass
Flonicamid	0.003/0.01	ND	0.01	Pass
Fludioxonil	0.003/0.01	ND	0.01	Pass
Hexythiazox	0.003/0.01	ND	0.01	Pass
Imazalil	0.003/0.01	ND	0.01	Pass
Imidacloprid	0.003/0.01	ND	0.01	Pass
Kresoxim Methyl	0.003/0.01	ND	0.01	Pass
Malathion	0.003/0.01	ND	0.01	Pass
Metalaxyl	0.003/0.01	ND	0.01	Pass
Methiocarb	0.003/0.01	ND	0.01	Pass
Methomyl	0.003/0.01	ND	0.01	Pass
Methyl parathion	0.003/0.01	ND	0.01	Pass
Mevinphos	0.007/0.02	ND	0.02	Pass
Myclobutanil	0.003/0.01	ND	0.01	Pass
Naled	0.003/0.01	ND	0.01	Pass
Oxamyl	0.003/0.01	ND	0.01	Pass
Paclobutrazol	0.003/0.01	ND	0.01	Pass
Pentachloronitrobenzene	0.003/0.01	ND	0.01	Pass
Permethrins	0.015/0.05	ND	0.05	Pass
Phosmet	0.003/0.01	ND	0.01	Pass
Piperonyl Butoxide	0.003/0.01	ND	0.01	Pass
Prallethrin	0.015/0.05	ND	0.05	Pass
Propiconazole	0.003/0.01	ND	0.01	Pass
Propoxur	0.003/0.01	ND	0.01	Pass
Pyrethrins	0.015/0.05	ND	0.05	Pass
Pyridaben	0.003/0.01	ND	0.01	Pass
Spinetoram	0.003/0.01	ND	0.01	Pass
Spinosad	0.003/0.01	ND	0.01	Pass
Spiromesifen	0.003/0.01	ND	0.01	Pass
Spirotetramat	0.003/0.01	ND	0.01	Pass
Spiroxamine	0.003/0.01	ND	0.01	Pass
Tebuconazole	0.003/0.01	ND	0.01	Pass
Thiacloprid	0.003/0.01	ND	0.01	Pass
Thiamethoxam	0.003/0.01	ND	0.01	Pass
Trifloxystrobin	0.003/0.01	ND	0.01	Pass
2-Phenylphenol	0.08/0.25	ND	0.25	Pass
3,4-Dichloroaniline	0.08/0.25	ND	0.25	Pass
Acetochlor	0.05/0.15	ND	0.5	Pass
Alachlor	0.05/0.15	ND	0.25	Pass
Allethrin	0.015/0.05	ND	0.05	Pass
Ametryn	0.03/0.10	ND	0.5	Pass
Aminocarb	0.03/0.10	ND	0.25	Pass

Analyte	LOD/LOQ (ppm)	Findings (ppm)	Limit (ppm)	Status
Ancymidol	0.02/0.06	ND	0.06	Pass
Anthraquinone	0.05/0.15	ND	0.25	Pass
Atrazine	0.007/0.02	ND	0.02	Pass
Azadirachtin	0.100/0.30	ND	0.3	Pass
Benzovindiflupyr	0.003/0.01	ND	0.01	Pass
Biphenyl	0.08/0.25	ND	0.25	Pass
Buprofezin	0.003/0.01	ND	0.01	Pass
Carbendazim	0.03/0.10	ND	0.5	Pass
Chlormequat Chloride	0.03/0.10	ND	0.1	Pass
Clothianidin	0.003/0.01	ND	0.01	Pass
Cyantraniliprole	0.003/0.01	ND	0.01	Pass
Cycloate	0.08/0.25	ND	0.5	Pass
Cyhalothrin (Lambda)	0.030/0.10	ND	0.1	Pass
Cyprodinil	0.03/0.10	ND	0.1	Pass
Cyromazine	0.03/0.10	ND	0.5	Pass
DCPA (Dacthal, Chlorthal-dimethyl)	0.03/0.10	ND	0.5	Pass
Deltamethrin I/II	0.015/0.05	ND	0.05	Pass
Diclobutrazol	0.02/0.06	ND	0.5	Pass
Diflubenzuron	0.08/0.25	ND	0.5	Pass
Dinotefuran	0.007/0.02	ND	0.02	Pass
Diphenylamine	0.08/0.25	ND	0.5	Pass
Diuron	0.007/0.02	ND	0.02	Pass
Dodemorph	0.003/0.01	ND	0.01	Pass
Endosulfan I (alpha)	0.015/0.05	ND	0.05	Pass
Endosulfan II (beta)	0.015/0.05	ND	0.05	Pass
Endosulfan Sulfate	0.015/0.05	ND	0.05	Pass
Ethirimol	0.02/0.06	ND	0.5	Pass
Etridiazole	0.003/0.01	ND	0.01	Pass
Fensulfothion	0.003/0.01	ND	0.01	Pass
Fenthion	0.003/0.01	ND	0.01	Pass
Fenvalerate	0.015/0.05	ND	0.05	Pass
Fluopyram	0.003/0.01	ND	0.01	Pass
Flurprimidol	0.03/0.10	ND	0.1	Pass
Flutriafol	0.05/0.15	ND	0.5	Pass
Formetanate HCl	0.03/0.10	ND	0.1	Pass
Hexaconazole	0.05/0.15	ND	0.5	Pass
Hydramethylnon	0.05/0.15	ND	0.5	Pass
Indole-3-butyric Acid	0.08/0.25	ND	0.25	Pass
Indoxacarb	0.05/0.15	ND	0.5	Pass
Iprodione	0.015/0.05	ND	0.05	Pass
Kinoprene	0.015/0.05	ND	0.05	Pass
Mandipropamid	0.03/0.10	ND	0.5	Pass
Metaflumizone	0.08/0.25	ND	0.5	Pass
Methoprene	0.100/0.30	ND	0.3	Pass
Methoxyfenozide	0.02/0.06	ND	0.5	Pass
Metolachlor	0.05/0.15	ND	0.25	Pass
MGK 264	0.015/0.05	ND	0.05	Pass
Novaluron	0.007/0.02	ND	0.02	Pass
Nuarimol	0.05/0.15	ND	0.5	Pass
o,p'-DDD	0.03/0.10	ND	0.1	Pass
o,p'-DDE	0.03/0.10	ND	0.1	Pass
o,p'-DDT	0.03/0.10	ND	0.1	Pass
p,p'-DDD	0.03/0.10	ND	0.1	Pass
p,p'-DDE	0.03/0.10	ND	0.1	Pass
p,p'-DDT	0.03/0.10	ND	0.1	Pass
Pendimethalin	0.030/0.10	ND	0.1	Pass
Pentachloroanisole	0.10/0.30	ND	0.5	Pass
Phenothrin	0.030/0.10	ND	0.1	Pass
Pirimicarb	0.003/0.01	ND	0.01	Pass
Prometryne	0.02/0.06	ND	0.5	Pass
Propamocarb	0.08/0.25	ND	0.5	Pass
Propargite	0.08/0.25	ND	0.5	Pass
Propyzamide	0.05/0.15	ND	0.5	Pass
Pymetrozine	0.03/0.10	ND	0.5	Pass
Pyraclostrobin	0.003/0.010	ND	0.01	Pass
Pyrimethanil	0.03/0.10	ND	0.5	Pass
Pyriproxyfen	0.003/0.01	ND	0.01	Pass
Quinoxifen	0.03/0.10	ND	0.5	Pass
Resmethrin	0.007/0.02	ND	0.02	Pass
Spirodiclofen	0.050/0.15	ND	0.15	Pass

Analyte	LOD/LOQ (ppm)	Findings (ppm)	Limit (ppm)	Status
Sulfoxafloer	0.03/0.10	ND	0.25	Pass
Tau-Fluvalinate	0.08/0.25	ND	0.5	Pass
Tebufenozide	0.003/0.01	ND	0.01	Pass
Teflubenzuron	0.007/0.02	ND	0.02	Pass
Terbutryn	0.02/0.06	ND	0.25	Pass
Tetrachlorvinphos	0.003/0.01	ND	0.01	Pass
Tetramethrin	0.015/0.05	ND	0.05	Pass
Thiabendazole	0.007/0.02	ND	0.02	Pass
Thiobencarb	0.03/0.10	ND	0.5	Pass
Thiophanate-methyl	0.007/0.02	ND	0.02	Pass
Tricyclazole	0.02/0.06	ND	0.5	Pass
Triflumizole	0.05/0.15	ND	0.5	Pass

Residual Solvent Screen ✓ Pass

08/14/2025

Analyte	LOD/LOQ (ppm)	Findings (ppm)	Limit (ppm)	Status
1,1-Dichloroethene	2/4	ND	8	Pass
1,2-Dichloroethane	0.2/0.5	ND	1	Pass
Acetone	14/40	<LOD	5000	Pass
Acetonitrile	14/40	ND	410	Pass
Benzene	0.2/0.5	ND	1	Pass
n-Butane	14/40	ND	800	Pass
Chloroform	0.2/0.5	ND	1	Pass
Ethanol	14/40	141.00	5000	Pass
Ethyl acetate	14/40	ND	5000	Pass
Ethyl ether	14/40	ND	5000	Pass
Ethylene oxide	0.2/0.5	ND	1	Pass
n-Heptane	14/40	ND	500	Pass
n-Hexane	14/40	ND	100	Pass
Isopropyl alcohol	14/40	ND	500	Pass
Methanol	14/40	47.00	3000	Pass
Methylene chloride	0.2/0.5	ND	1	Pass
n-Pentane	14/40	ND	5000	Pass
Propane	14/40	ND	210	Pass
Toluene	14/40	ND	890	Pass
Total xylenes (ortho-, meta-, para-)	14/40	ND	2170	Pass
Trichloroethylene	0.2/0.5	ND	1	Pass

Heavy Metal Screen ✓ Pass

08/15/2025

Method: MF 24E020

Instrument: Inductively Coupled Plasma Mass Spectrometry (ICP-MS)

Analyte	LOD / LOQ (µg/g)	Findings (µg/g)	Limit	Status
Arsenic	0.02/0.05	ND	0.2	Pass
Cadmium	0.02/0.05	ND	0.2	Pass
Mercury	0.02/0.05	ND	0.1	Pass
Lead	0.02/0.05	ND	0.5	Pass

Foreign Material ✓ Pass

08/15/2025

Method: MF-CHEM-7

Analyte	Findings	Limit	Status
Sand, Soils, Cinders, and Dirt	ND	25%	Pass
Mold	ND	25%	Pass
Imbedded Foreign Material	ND	25%	Pass
Insect Fragment	ND	1 per 3g	Pass
Hair	ND	1 per 3g	Pass
Mammalian Excreta	ND	1 per 3g	Pass

Mycotoxin Screen

Method: MF-CHEM-13

Instrument: Liquid Chromatography Tandem Mass Spectrometry (LC-MS/MS) & Gas Chromatography Tandem Mass Spectrometry (GC-MS/MS)

Analyte	LOD/LOQ (ppb)	Findings (ppb)	Limit (ppb)	Status
Aflatoxin B1	2/5	ND	-	-
Aflatoxin B2	2/5	ND	-	-
Aflatoxin G1	2/5	ND	-	-
Aflatoxin G2	2/5	ND	-	-
Total Aflatoxins	8/20	ND	20	Pass
Ochratoxin A	6/18	ND	20	Pass

ND = None Detected
 LOD = Limit of Detection
 LOQ = Limit of Quantitation

Reported by




Vu Lam
 Lab Co Director



Scan to verify